



JetWave IWC 5630 Series Industrial-grade WLAN controller

User Manual

V1.0 Sep.15, 2015



Copyright

Copyright © 2014 all rights reserved. No part of this publication may be reproduced, adapted, stored in a retrieval system, translated into any language, or transmitted in any form or by any means without the written permission of the supplier.

About This Manual

This user manual is intended to guide professional installer to install the JetWave IWC 5630 and how to build the infrastructure centered on it. It includes procedures to assist you in avoiding unforeseen problems.

Conventions

For your attention on important parts, special characters and patterns are used in this manual:

Note:

This indicates an important note that you must pay attention to.

The Blue Wording is important note that you must pay attention to.

The Blue Wording with Big Case is very important note you must pay more attention to.

A Warning:

This indicates a warning or caution that you have to abide.

The Red wording is very important you must avoid.

Bold: Indicates the function, important words, and so on.



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To avoid the possibility of exceeding radio frequency exposure limits, you shall beep a distance of at least 100cm between you and the antenna of the installed equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.



Content

Cha	pter	⁻ 1 In	troduction	2
1	.1	Intro	oduction	2
1	.2	JetV	Nave IWC 5630 Series Appearance	3
1	.3	JetV	Nave IWC 5630 Major Features	3
1	.4	Sup	ported AP models	4
1	.5	Prod	duct Package	4
Cha	apter	2 Ha	ardware Installation	6
2	.1	Prof	fessional Installation Required	6
	Safe	ety P	Precautions	6
2	.2	Pow	ver Installation	6
	2.2.	1	DC Input	6
2	.3	Pow	ver Installation	7
	2.3.	1	Wiring your Ethernet Port	7
	2.3.	2	SFP socket	7
	2.3.	3	USB port	7
	2.3.	4	Reset	7
	2.3.	5	Serial port	8
	2.3.	6	Serial port	9
	2.3.	7	Ground	9
2	.4	LED	D Indicator 1	0
Cha	apter	3 Pı	repare for Management 1	2
3	.1	Bas	ic Factory Default Settings 1	2
3	.2	Sys	tem Requirements 1	2
3	.3	How	v to Login the Web-based Interface1	3
3	.4	Fail	to login the Web GUI 1	3
Cha	apter	4 W	/eb GUI Configuration 1	6
4	.1	Mor	nitor1	6



4.1.1	Information16
4.1.2	Access Points
4.1.3	Statistics
4.1.4	Event/Alarm
4.2 S	ystem 19
4.2.1	Basic Settings 19
4.2.2	Time Settings
4.3 A	ccess Points
4.3.1	AP Settings
4.3.1.	AP model settingsWIFI 22
4.3.1.	2 AP model settingsCellular
4.3.1.	3 Per-AP settings
4.4 V	/LANs
4.4.1	WLAN profile
4.5 N	letwork Settings
4.5.1	IP Settings
4.5.2	Bridge Table
4.5.3	ARP Table
4.5.4	DHCP Client List
4.5.5	NAT settings
4.6 S	ecurity
4.6.1	Firewall settings
4.6.2	MAC ACL
4.7 A	AA
4.7.1	Radius settings
4.7.2	Radius server
4.8 N	lanagement
4.8.1	Remote Setting
4.8.2	SMTP Configuration
4.8.3	Password Settings



4.8.4	Firmware Upgrade 4	7
4.8.5	Configuration File 4	8
4.8.6	Certificate File 4	9
4.9 Too	ols5	60
4.9.1	System Log 5	60
4.9.2	Ping 5	51
4.10 N	/ain Entry5	52
4.10.1	Save	52
4.10.2	Logout5	52
4.10.3	Reboot 5	52
Chapter 6 T	roubleshooting	5
5.1 Ger	neral Question	5
5.1.1	How to know the MAC address of the WLAN controller?5	55
5.1.2	What if I would like to reset the unit to default settings?	5
5.1.3	What if I cannot access the Web-based management interface?	5
Revision Hi	story5	6







Chapter 1 Introduction

Chapter 1 Introduction

1.1 Introduction

The user manual is applied to Korenix JetWave IWC 5630 Series Industrial-grade WLAN controller. For detail product specification, please download the latest datasheet from Korenix web site.

1.2 JetWave IWC 5630 Series Appearance




Figure - JetWave IWC 5630 Appearance

1.3 JetWave IWC 5630 Major Features

- Central-managed wireless network: Integrated AP auto discovery and auto provision for fast
 installation and deployment
- Enhanced wireless security: Minimal deployment for built-in secure gateway and built-in RADIUS server
- · Advanced wireless mobility: Less than 100ms server-based fast roaming
- WPA2-personal/enterprise and IEEE 802.11i-compliant wireless security
- IEEE 802.1x/RADIUS supported
- Up to 25 managed APs and 1000 concurrent users
- Up to 8 WLAN radio profiles supported & 8 VAPs per profile
- IP30 grade sheet metal chassis
- -40~75°C operating temp
- DC 9~36V power input with polarity auto reverse protection
- EN50022 DIN-rail mount



1.4 Supported AP models

Supported AP models are JetWave 3200 series include all JetWave 3200/3300/3400 product series with dedicated firmware. Please make sure you are using controller-based AP firmware.

1.5 Product Package

The product package you have received should contain the following items. If any of them are not included or damaged, please contact your local vendor for support.

Package:

JetWave IWC5630 Unit Din-Rail Mounting Kit 2-pin Power connector Quick Installation Guide Console cable (3pin/DB9) Note: Please download the Utility, User Manual from Korenix Web Site.

Note 1: Check the Korenix web site order information for new accessories, new version user manual, MIB file, firmware and Utility.

Note 2: Different model needs different number of the accessories. If you are not familiar with the feature of the accessories, please consult with our Sales or Technical Service Engineer.







Chapter 2 Hardware Installation

Chapter 2 Hardware Installation

This chapter describes safety precautions and product information before installing JetWave IWC 5630 Series.

2.1 Professional Installation Required

- Please seek assistance from a professional installer for field installation or professional IT Engineer for indoor installation.
- 2. The JetWave IWC 5630 series is distributed through distributors and system installers with professional technicians and will not be sold directly through retail stores.

Safety Precautions

- 1. To keep you safe and install the hardware properly, please read and follow these safety precautions.
- 2. If you are installing JetWave IWC 5630 series in the field box, for your safety as well as others', please seek assistance from a professional installer who has received safety training on the hazards involved. Keep safety as well as performance in mind when selecting your installation site, especially where there are electric power and phone lines. Please note the following things as well:
 - Do not use a metal ladder;
 - Do not work on a wet or windy day;
 - Wear shoes with rubber soles and heels, rubber gloves, long sleeved shirt or jacket.
- 3. If you are installing JetWave IWC 5630 series in the indoor office or factory, be aware of the power source and grounding must be well installed.
- 4. Note that Field EMD (Lightning) DAMAGE IS NOT COVERED UNDER WARRANTY.

2.2 Power Installation

The system provides DC power input.

2.2.1 DC Input

1. There is one 2-pin terminal block within the package for screwing the DC wires. It is a good practice to turn off the system power, and to unplug power terminal block before making wire



connections.

- Insert the positive and negative wires into the V+ and V- contact on the terminal block connector. Tighten the wire-clamp screws to prevent DC wires from being loosened. The range of the suitable electric wire is from 12 to 24 AWG.
- The typical and suggest power source is DC 24V, the acceptable range is range from 9~36V.
 Please note that while you connect 36VDC, make sure the inrush voltage shall be under 10% (39.6V).

2.3 Power Installation

2.3.1 Wiring your Ethernet Port

There are four Gigabit Ethernet ports. The 4 ports are standard RJ-45 form factor. They can support 10Base-TX, 100Base-TX and 1000Base-T. The 10/100Base-TX also supports both full and half duplex mode. All the Ethernet ports will auto-detect the signal from connected devices to negotiate the link speed and duplex mode. Auto MDI/MDIX allows users to connect another switch, hub or workstation without changing straight through or crossover cables. In some cases, the MDI/MDI-X may requests the connected device support auto-negotiation.

Available Cable Type:

10Base-T: 2-pair UTP/STP Cat. 3, 4, 5 cable (100m)

100 Base-TX: 2/4-pair UTP/STP Cat. 5 cable (100m)

1000 Base-T: 4-pair UTP/STP Cat. 5 cable (100m)

2.3.2 SFP socket

SFP socket is 100/1000 fiber SFP socket combo, combo with 10/100/1000Base-T. It can be used as a WAN port.

2.3.3 USB port

The port supports USB flash device. This interface is reserved for future requirement.

2.3.4 Reset

There is one Reset button located at the bottom of the device. This is design for user to reboot the system port or force reset the configuration to default. The function is depended on how much time you press the button.

Press 3 seconds to reboot the device.



Press more than 7 seconds can reset the configuration to default.

2.3.5 Serial port

There is one RS232 serial port for serial communication. The port supports RS232/422/485

3-in-1. This interface is reserved for future requirement.

Below figure shows the pin assignment of the serial port.




Pin 1: DCD	Pin 2: RXD	Pin 3: TXD
Pin 4: DTR	Pin 5: GND	Pin 6: DSR
Pin 7: RTS	Pin 8: CTS	Pin 9: RI



There is one 3-pin console for diagnostic and command line on the bottom of the device. The 3 pin indicates below pin assignment of the typical RS-232 serial connection. You can wire the cable by yourself or purchase from Korenix.

	Pin 1	Pin 2	Pin 3
Diag. Socket	GND(Ground)	Receive Data (RD)	Transmit Date (TD)
D-Sub 9	GND(Ground)	Transmit Date (TD)	Receive Data (RD)





2.3.7 Ground

To ensure the system will not be damaged by noise or any electrical shock, we suggest you to make exact connection with the Earth Ground. There is one earth ground screw on the bottom side of the device. Loosen the earth ground screw then tighten the screw after earth ground wire is connected.



2.4 LED Indicator

The following table indicates the LED of your device.

LED	Indication	LED	Indication
DW/D	Power Status	S1	Status for Customization
PWR	Green ON = System ON		(Green or Amber)
	Status for Customization		Status of the SFP socket
S2		SFP	1000Mbps (Green on) / 100Mbps
			(Amber on)
Ethernet	Link (Green on) / Activity (Green	Ethernet	1000Mbps (Amber on) / 10 or
Port	blinking)	Speed	100Mbps (Amber off)







Chapter 3

Prepare for Management

Chapter 3 Prepare for Management

Using Web GUI Configuration to setup JetWave IWC 5630 Series.

This chapter describes the preparation for management. In your first time access the device, you can refer to the Basic Factory Default Settings to know the default settings and the default IP of the device.

Basic Factory Default Settings 3.1

We'll elaborate the JetWave IWC 5630 Series basic factory default settings. You can re-acquire these parameters by default. This info is easier for you to find the device and access the WLAN controller's configuration interface. For further info, please refer to configuration guide of the feature set.

le 1 JetWave IWC 5630 Basic Factory Default Settings				
Features	Factory Default Settings			
Username	admin			
Password	admin			
Model Name	IWC 5630			
Device Name	korenixXXXXXX (X represents the last 6			
	digits of Ethernet MAC address)			
Default IP				
IP Address	192.168.10.1			
Subnet Mask	255.255.255.0			
Gateway	0.0.0.0			
Console Type	3-pin (Tx, Rx, GND), 115200, N/8/1			

Tab

System Requirements 3.2

Before configuration, please make sure your system meets the following requirements:

A computer coupled with 10/100/1000 Base-T(X) adapter;

Configure the computer with a static IP address of 192.168.10.x (X cannot be 0, 1, nor 255), as the default IP address of JetWave IWC 5630 Series is 192.168.10.1 (Eth 1/2/3 of IWC 5630).

A Web browser on PC for configuration such as Microsoft Internet Explorer 6.0 or above, Google Chrome or Firefox is preferred.

Note: If you want to do throughput test, not just configure the switch, please notice that the throughput of the high performance and low performance CPU must be different.



3.3 How to Login the Web-based Interface

The system provides you with user-friendly Web-based management tool.

Open Web browser and enter the IP address (Default: **192.168.10.1**) into the address field. You will see the WELCOME page as below.

Your Industrial Computing & Networking Partner	
Welcome to the JetWave IWC 5630 Industrial-grade WLAN controller	
Name admin	
Password	

Figure – Web GUI Login Page

Enter the name of Account (Default: admin) and password (Default: admin) respectively and click "Login" to login the main page of the device. As you can see, this management interface provides main options in the above, which are Monitor, System, Access points, WLANs, Network Settings, Security, AAA, Management, Tools, Save, Logout and Reboot. Remember to save to flash after configuration applied to keep consistency between system reboot.



The username and password are case-sensitive!

3.4 Fail to login the Web GUI

If you failed to login the web GUI, there are something you can do for troubleshooting.

 Korenix web management page is developed by JAVA. It allows you to use a standard web-browser such as Microsoft Internet Explorer, or Mozila, to configure and interrogate the switch from anywhere on the network. The IE 5.0 or later versions do not allow Java applets to open Page 13

Beijer korenix

JetWave IWC 5630 Series User Manual

sockets by default. Users have to directly modify the browser settings to selectively enable Java applets to use network ports.

- Please disable the firewall setting of your browser. The firewall setting may block the connection from your PC to the device. The firewall may stop the firmware upgrade, configuration backup and restore as well. Note that after finished the setting, re-enable your firewall to protect your PC.
- 3. Check the IP Setting, your PC and managed device must be located within the same subnet.
- 4. The Web UI connection session of the device will be logged out automatically if you don't give any input after 30 seconds. After logged out, you should re-login and key in correct user name and password again.
- 5. The new JAVA version may have different security policy in different versions, please contact Korenix engineer (Korecare@korenix.com) once you have problem for login.







Chapter 4 Web GUI Configuration

Chapter 4 Web GUI Configuration

This chapter describes the Web GUI for Software Configuration.

4.1 Monitor

The Monitor feature set includes Information, Access point, Statistics and Event/alarm.

4.1.1 Information

This page shows the current status and some basic setting of the device.

Information

This page shows the current status and some basic settings of the device.

System Information

Model Name	IWC 5630
Device Name	korenix9b7eab
Country/Region	United States
Firmware Version	0.9b1

WAN Settings

Access Type	Static IP
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Default Gateway	192.168.1.254
DNS1	0.0.0.0
DNS2	0.0.0.0
MAC Address	bc:6a:29:9b:7e:ac

LAN Settings

IP Address	192.168.10.1
Subnet Mask	255.255.255.0
MAC Address	bc:6a:29:9b:7e:ab

Port Status

Interface	MAC Address	Status	Rate
Lan:1	bc:6a:29:9b:7e:ab	Down	
Lan:2	bc:6a:29:9b:7e:ab	Up	1000M/full-duplex
Lan:3	bc:6a:29:9b:7e:ab	Up	1000M/full-duplex
Wan	bc:6a:29:9b:7e:ac	Down	

System Information: The Model Name, Device Name, Country/Region you selected and Firmware version number.



WAN Setting: It shows the Access type, IP Address, Subnet Mask, Default Gateway, DNS 1/2 and MAC Address of the WAN interface.

LAN Setting: It shows the IP Address, Subnet Mask and MAC Address of the LAN interface.

Port Status: This table shows the Interface Name, MAC Address, Status and Rate.

4.1.2 Access Points

This table shows instant APs list that are discovered by IWC 5630.

The status field can be pending, connecting and connected. Pending implies the AP are discovered but not approved. Connecting applies the AP is during the process of approval. When status is connected, it implies the AP is managed by IWC 5630.

In action field, you can decide to approve specific AP to be managed by IWC 5630.

WLAN controller IWC 5630		ist shows the currently I Interval: 5		oints. I-65534) sec Set	Interval	Stop	
🗉 🧰 System	Index \$	MAC Address 🖨	Model 🗢	Name 🜩	Status≑	IP	Action
🕀 🧰 Access Points	1	00:12:77:31:00:0c	JetWave3220	korenix31000c	Pending	192.168.10.	2 Approve
🕀 🧰 WLANs							
Network Settings				Refresh			
B Security							
AAA							
🕀 🧰 Management							
Tools Save Logout Reboot							

Poll Interval: The poll interval time setting, range from 0~65534 seconds. If you want to change the poll interval time, press "Stop" and then enter new value, press "Set Interval" to activate new setting.

Set Interval: Set new Interval time after enter new poll interval time.

Stop: Stop polling the associated clients.

4.1.3 Statistics

This page shows the packet counters for transmission and reception regarding to LAN port and WAN port.



Monitor Monitor Monitor Access points Statistic Event/alarm System	Statistics This page shows the packet coun ethernet networks. Poll Interval: 5		reception regarding to wire
Access Points		Received	Transmitted
WLANs	Lan Port	r	
Network Settings	Total Packets	19382	28085
_	Total Bytes	2093884	27667431
Security	Wan Port		
B AAA	Total Packets	0	31
Management	Total Bytes	0	2042
 Tools Save Logout Reboot 		Refresh	

Poll Interval: The poll interval time setting, range from 0~65534 seconds. If you want to change

the poll interval time, press "Stop" and then enter new value, press "Set Interval" to activate.

Set Interval: Set new Interval time after enter new poll interval time.

Stop: Stop polling the associated clients.

4.1.4 Event/Alarm

This table shows system events. You can observe system activities here, for example, AP joined,

AP disconnected or AP deleted, etc.

WLAN controller IWC 5630			arm l	-	r and show the system log.	
Event/alarm	#\$	Date≑	Time≑	Level ¢	Event	÷
🕀 🧰 System	1	Aug 20	18:25:34	Medium	AP [00:12:77:31:00:0c] joined WLAN controller.	
🕀 🧰 Access Points	2	Aug 20	18:26:27	Medium	AP [00:12:77:31:00:0c] deleted	
🕀 🧰 WLANs	3	Aug 20	18:26:53	Medium	AP [00:12:77:31:00:0c] joined WLAN controller.	
🗉 🧰 Network Settings						
E Security					Refresh	
🕀 🧰 Management						
Tools						
- Cave - Logout - Reboot						

4.2 System

For users who use the JetWave IWC 5630 series for the first time, it is recommended that you begin configuration from the "**System**" page shown below:

In **System** pages, there are some configuration pages for the system settings. These setups are introduced in below pages.

4.2.1 Basic Settings

Use this page to configure the basic parameters of the device.

Basic Settings

Use this page to configure the basic parameters of device.

Device Settings

Device Name:	korenix9b7eab (max. 15 characters and no spaces)
Lan Port : 1 DataRate:	Auto
Lan Port : 2 DataRate:	Auto
Lan Port : 3 DataRate:	Auto
Wan Port : DataRate:	Auto
Country/Region:	United States 🔻
802.1Q VLAN:	Enabled
Management VLAN ID:	0

Apply Cancel

Device Name: User could give a name for identifying a particular access point here. It allows

maximum 15 characters and no spaces.

Lan port: 1/2/3 Data Rate: Configure the Speed/Duplex of the port Eth 1. The default value,

Auto means Auto-Negotiation. Force speed/duplex is available to setup here.



Basic Settings

Use this page to configure the basic parameters of device.

Device Settings

Device Name:	korenix9b7eab (max. 15 characters and no spaces)
Lan Port : 1 DataRate:	Auto
Lan Port : 2 DataRate:	Auto 10M/full-duplex
Lan Port : 3 DataRate:	100M/full-duplex
Wan Port : DataRate:	10M/half-duplex 100M/half-duplex
Country/Region:	United States
802.1Q VLAN:	Enabled
Management VLAN ID:	0

Wan port: Data Rate: the setting is the same as Lan port Data rate.

<u>Country/Region</u>: Select the country you are installed. The channel number may be different based on your country.

802.1Q VLAN: Enable or Disable 802.1Q VLAN. With 802.1Q enabled, the packet will attach the 1Q VLAN tag inside. To assign the VLAN ID for each AP profile, you should enable 802.1Q VLAN first. Here is the global VLAN Enable setup.

<u>Management VLAN ID</u>: This is the management VLAN ID of the device. Only the client within the same management VLAN can access the device's management interface. To enable Management VLAN ID, you must enable "802.1Q VLAN" and assign "VLAN ID" for each AP profile first.

4.2.2 Time Settings

Use this page to configure the **Time Settings**. You can configure current time, time zone and configure NTP protocol to synchronize system time with a public time server over the internet.



Time Settings

You can synchronize System Log's time stamp with a public time server over the Internet.

Current Time:	Yr 2014 Mon 6 Day 19 Hr 10 Mn 58 Sec 56 Get PC Time
Time Zone :	(GMT)Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London 🗸
NTP:	Enable NTP client update
O NTP server:	192.5.41.41 - North America 🗸
Manual IP:	0.0.0.0

Apply	Cance	el

<u>Current Time</u>: You can manually type the current time or get the time from you PC. Click "Get PC time", the current time will be updated according to your PC's time.

Time Zone Select: Select the time zone of your country from the dropdown list.

<u>NTP:</u> You can select "Enable NTP client update" in this page, then the NTP feature will be activated and synchronize from the remote time server.

NTP Server: Select the time server from the <u>"NTP Server</u>" dropdown list or manually input the IP address of available time server into <u>"Manual IP"</u>.

Press "Apply" to activate the settings.

4.3 Access Points

In Access Points category, you can set pre-configured AP model setting and per-AP settings for APs that are managed by IWC 5630. Pre-configured AP model settings are categorized by AP model. For example, JetWave 3220 has dual radios. You can configure +radio settings for each radio and all JetWave 3220 share the same AP model settings by default.

For specific AP configuration, per-AP setting is also supported for dynamic RF environment. For example, AP model setting set to channel 6 and per-AP model setting set to channel 11. Once per-AP settings applied, it will override model radio settings.

To clear an AP from IWC 5630 system, you can "delete AP" and AP-related information will be removed. In such circumstance, the AP will be viewed as a brand-new AP in AP discovery stage.

4.3.1 AP Settings

Use this page to configure the parameters for wireless LAN access points.



AP Settings

Use this page to configure the parameters for wireless LAN Access Point.

ModelList 🔹

Per-AP Setting

1 00:12:77:31:00:0c JetWave3420 korenix31000c Connected 192.168.10.2 Edit D	Index	MAC Address	Model	Name	Status	IP	Ac	tion
00;12;77;51;00;0C Jetwave5420 Kolenix51000C Connected 192:106.10.2 Edit	1	00:12:77:31:00:0c	JetWave3420	korenix31000c	Connected	192.168.10.2	Edit	Delete

Model list: Supported JetWave AP models will be listed in the list. Select the model you want to

configure and the related settings will be display below. Radio selection will be on the right of

Model list.

4.3.1.1 AP model settings --WIFI

Use this page to configure WIFI radio of JetWave devices. The following picture uses JetWave 3220 as example.

AP Settings

Use this page to configure the parameters for wireless LAN Access Point.

 JetWave3220
 VIFI1

Auto-Approval (Automatically approve join request of this AP model)

Disable Wireless LAN Interface

Model Name:	JetWave3220
802.11 Mode:	802.11G/N T
Frequency/Channel:	2437MHz (6) 🔻
Extension Channel:	None 🔻
Channel Mode:	20 MHz 🔻
WLAN Profile:	Default 🔻

Show Advanced Setting

These settings are only for more technically advanced users.

Auto-Approval: Check the button to automatically approve join requests from the APs if you do

not want to manually approve each AP of them.

Disable Wireless LAN Interface: Check this option to disable WLAN interface, then the

wireless module of the AP will stop working and no wireless device can connect to it.

Model name: The field shows the model name of the AP, not editable.




802.11 Mode: The AP/Gateway can communicate with wireless devices of 802.11n/a/g. You can also select 802.11A only, 802.11G only, 801.11A/N and 802.11 G/N and make it work under an appropriate wireless mode automatically.

Frequency/Channel: Channel varies much as the available band differs from country to country. Select a proper operating channel in the drop-down list according to your situation.

The 802.11G and 802.11G/N are 2.4G band which supports 12~13 channels.

The 802.11A and 802.11A/N are 5.8G band, this product support Band 1 (36, 40, 44, 48) and Band 4 (149, 153, 157, 161, 167)



Extension Channel : The attribute will be only displayed when using 802.11 A/N mode.

<u>Channel Mode:</u> Two levels are available: 20MHz and 20/40MHz. The latter one can enhance the data rate more effectively, but takes more bandwidth, thus cause potential interference. The attribute will be only displayed when using 802.11 A/N mode.

Channel Mode 20 MHz 20/40 MHz 40 MHz

<u>WLAN Profile:</u> Select the WLAN profile for this radio. Please refer to section 4.4 WLAN category for the configuration of WLAN profile.

Check "**Show Advanced Setting**" to proceed advance settings. These settings are only for more technically advanced users who have a sufficient knowledge about wireless LAN. Some of these settings should not be changed unless you know what effect the changes will take. And some of the modification on them may negatively impact the performance of your wireless network.



Show Advanced Setting

These settings are only for more technically advanced users.

HT protect:	Enabled
Maximum Output Power :	Full 🔻
Data Rate:	Auto 🔻
Extension Channel Protection:	None 🔻
WMM Support:	Enabled Disabled
A-MPDU aggregation:	Enabled Oisabled
A-MSDU aggregation:	Enabled Disabled
Short GI:	Enabled
RTS Threshold:	2347 (1-2347)
Fragment Threshold:	2346 (256-2346)
Beacon Interval:	100 (20-1024 ms)
DTIM Interval:	1 (1-255)
Preamble Type:	🕞 Long 💿 Auto
IGMP Snooping:	Enabled Oisabled
RIFS:	Enabled Disabled
Link Integration:	Disable 🔻
Space In Meter:	0 (0-15000 m)

Apply	Cancel
-------	--------

<u>HT Protect</u>: Enable HT (High Throughput) protect to ensure HT transmission with MAC mechanism. Under 802.11n mode, wireless client can be divided into HT STA and Non-HT STA, among which the one with HT protect enabled gets higher throughput.

Maximum Output Power: Specify the signal transmission power. The higher the output power is, the wider the signal can cover, but the power consumption will be greater accordingly. Usually "**Full**" with proper antenna is preferred.

Half: 1/2 of Full (Full -3dBm), Quarter: 1/4 of Full (Full -6dBm), Eighth: 1/8 of Full (Full – 9dBm).

Half	Maximum Output Power (per	Full 🔻
Data Rate: Quarter Half	chain):	
Half	Data Rate:	
	Extension Channel Protection:	

Date Rate: Usually "Auto" is preferred. Under this rate, the AP/Gateway will automatically select the highest available rate to transmit. In some cases, however, like where there is no



great demand for speed, you can have a relatively-low transmit rate for compromise of a long

distance.

802.11A, 11G	802.11N
Auto 6M 9M 12M 18M 24M 36M 48M 54M	Auto 6M 9M 12M 18M 24M 36M 48M 54M MCS0-6.5[13.5] MCS1-13[27] MCS1-13[27] MCS2-19.5[40.5] MCS2-19.5[40.5] MCS3-26[54] MCS4-39[81] MCS5-52[108] MCS6-58.5[121.5] MCS7-65[135] MCS7-65[135] MCS8-13[27] MCS9-26[54] MCS10-39[81] MCS10-39[81] MCS11-52[108] MCS12-78[162] MCS13-104[216] MCS14-117[243] MCS15-130[270]

Extension Channel Protection: This is to avoid conflict with other wireless network and boost the ability of your device to catch all 802.11g transmissions. However, it may decrease wireless network performance. Compared to CTS-Self; the transmission amount of CTS-RTS is much lower.

WMM Support: WMM (Wi-Fi Multimedia) is a subset of 802.11e. It allows wireless communication to define a priority limit on the basis of data type, thus those time-sensitive data, like video/audio data, may own a higher priority than common one.

<u>A-MPDU/A-MSDU Aggregation</u>: Under AP mode, the data rate of your AP could be enhanced greatly with this option enabled; however, if your wireless clients don't support A-MPDU/A-MSDU aggregation, it is recommended not to enable it.

<u>Short GI:</u> Under 802.11n mode, enable it (Short Guard Interval) to obtain better data rate if there is no negative compatibility issue.

<u>RTS Threshold:</u> The AP/Gateway sends RTS (Request to Send) frames to certain receiving station and negotiates the sending of a data frame. After receiving an RTS, that STA responds with a CTS (Clear to Send) frame to acknowledge the right to start transmission. The setting



range is 0 to 2347 in byte.

<u>Fragmentation Threshold:</u> Specify the maximum size in byte for a packet before data is fragmented into multiple packets. Setting it too low may result in poor network performance. Leave it at its default of 2346 is recommended.

Beacon Interval: Specify the frequency interval to broadcast packets. Enter a value between 20 and 1024. The default value is 100ms.

<u>DTIM Interval</u>: DTIM, which stands for Delivery Traffic Indication Message, is contained in the data packets. It is for enhancing the wireless transmission efficiency. The default is set to 1. Enter a value between 1 and 255.

<u>Preamble Type</u>: It defines some details on the 802.11 physical layer. "Long" and "Short" are available.

IGMP Snooping: IGMP snooping is the process of listening to IGMP network traffic. By enabling IGMP snooping, the AP will listen to IGMP membership reports, queries and leave messages to identify the ports that are members of multicast groups. Multicast traffic will only be forwarded to ports identified as members of the specific multicast group or groups.

<u>RIFS</u>: RIFS (Reduced Interframe Spacing) is a means of reducing overhead and thereby increasing network efficiency.

<u>Link Integration</u>: This is also known as Link Fault Pass-Through. This feature allows you to bind the Ethernet port 1 (Eth1) and Wireless LAN interface together. Once one of them fails, the other interface becomes down as well.

Link Integration:	Disable
Space In Meter:	WLAN links LAN LAN links WLAN
Antenna Number:	WLAN and LAN link each other

Disable: Disable the Link Integration.

WLAN links LAN: Single direction only while the WLAN failure, the binding Ethernet port will become link down.

LAN links WLAN: Single direction only while the LAN Ethernet port failure, the binding WLAN radio will be shut down.

WLAN and LAN link each other: This is Bi-directional integration no matter while LAN Ethernet port failure or WLAN radio failure.



Space in Meter: To decrease the chances of data retransmission at long distance, the AP/Gateway can automatically adjust proper ACK timeout value by specifying distance of the two nodes. This is very important especially for long distance transmission. Correct Space in Meter helps to get better response time and performance.

Press "Apply" to activate the new setting.

4.3.1.2 AP model settings --Cellular

Use this page to configure cellular radio of JetWave devices. The following picture uses JetWave 3320 as example.

AP Settings

Use this page to configure the parameters for wireless LAN Access Point.

JetWave3320 ▼ Cellular ▼

Auto-Approval (Automatically approve join request of this AP model)

Disable Cellular Interface

APN:	internet	
User Name:		
Password:		
Authentication Type:	CHAP O PAP	
Auto Reconnect:	Enable Disable	
WAN Redundancy:	Fixed Cellular 🔻	

Enable Auto IP Report		
IP Report to URL:		

<u>Auto-Approval</u>: Check the button to automatically approve join requests from the APs if you do not want to manually approve each AP of them.

Disable 3G/Cellular Interface: You can disable the 3G/LTE interface manually.

<u>APN:</u> Every ISP has a specific APN (Access Point Name) assigned to its cellular network. The system can read this name from the SIM card. You can also find this setting by contacting your ISP to know this. Once you failed to connect your 3G/LTE cellular network, this is the first way you can check. Please check with your ISP to know the APN and correctly input the setting through the page.

Beijer korenix

JetWave IWC 5630 Series User Manual

User Name: The user name for the 3G/LTE connection. Normally, this is provided by your ISP.

Password: The password for the 3G/LTE connection. Normally, this is provided by your ISP.

<u>Authentication Type:</u> You can select CHAP or PAP per your ISP request. Normally, this is provided by your ISP.

Reconnection Delay: Reconnection Delay time is the delay time for each 3G/LTE Retry.

Reconnection Retries: This is the times of Reconnection Retry. While 3G/LTE is not connected, the system will retry the connection according to the Reconnection Delay time and Retry times.

WAN Redundancy: The product can support WAN redundancy feature.

In default, the setting is **Fixed 3G/Cellular**, that means you can use 3G/LTE and Ethernet WAN port at the same time.

You can change the settings to **WAN First.** WAN first means the 3G/LTE feature is only activated when the Ethernet WAN port link down or failure.

Auto IP Report:

Most of the ISP assigns the dynamic IP address to the 3G/LTE clients and change the IP address every period of time. While you need to remotely control the gateway, you may need additional information generated from the remote 3G/LTE client device. The Auto IP Report in JetWave 3320/3420 can meet your need while you need to know the IP address from the product.

<u>Enable Auto IP Report</u>: Press Enable Auto IP Report, the system will automatically update the system information to remote server/URL.

<u>IP Report to URL:</u> Type the correct URL here for your Gateway report to. You can build your own server, rent URL address from ISP or Google Cloud service also supports this functionality. Please check with your ISP or create through Google cloud.

Press "Apply" to activate the new setting.

4.3.1.3 Per-AP settings

Currently managed AP will be listed in per-AP setting. Click **Edit** to enter Per-AP setting configuration page. The description of the AP will be displayed when mouse pointer over **Edit** button. This is helpful to make sure you are configuring the AP you want. You can click the MAC



address to retrieve the current settings of the AP.

AP Settings

Use this page to configure the parameters for wireless LAN Access Point.

 ModelList

 Per-AP Setting
 Index
 MAC Address
 Model
 Name
 Status
 IP
 Action

 1
 00:12:77:31:00:0c
 JetWave3420
 korenix31000c
 Connected
 192.168.10.2
 Edit
 Delete

Please refer to 4.3.1.1 and 4.3.1.2 for the settings of WIFI and cellular settings for specific AP

settings.

Per AP Settings

Use this page to configure the parameters for wireless LAN Access Point.

Disable Wireless LAN Interface

Description	
Mac Address:	00:12:77:31:00:86
Model Name:	JetWave3220
802.11 Mode:	802.11G/N T
Frequency/Channel:	2437MHz (6) 🔻
Extension Channel:	None 🔻
Channel Mode:	20 MHz 🔻
WLAN Profile:	Default 🔻

Show Advanced Setting

These settings are only for more technically advanced users.

4.4 WLANs

In **WLAN** category, you can configure WLAN profiles for AP radios. Up to 8 WLAN profiles are supported. There will be a default WLAN profile that functions as the default settings of WIFI radio. Default WLAN profile can't be deleted but editable. Click **Add** button to create a new WLAN profile and click **Edit/Del** to edit/delete an existing WLAN profile.



WLAN controller IWC 5630			
🕀 🧰 Monitor	WLAN	Profile	
🕀 🧰 System	Use this pa	ge to set the radio VAP	
		ye to bet the rune run	·
🖨 🔄 WLANs	Select	Profile Name	Profile Description
🖳 🗋 WLAN Profile		Default	Profile default setting
🕀 🧰 Network Settings			
🕀 🧰 Security			
AAA			Add Edit Del
🗈 🧰 Management			
🗉 🧰 Tools			
- 🗋 Save			
- D Logout			
🗄 🛅 Reboot			

4.4.1 WLAN profile

In WLAN profile settings configuration page, you can configure the profile name and description. You can have an outlook of all VAP settings in the page and up to 8 VAP profiles can be configured. Click **Enable** checkbox to enable a configured VAP in the WLAN profile. Click **Edit** to edit the settings of the VAP.

WLAN controller IWC 5630 Monitor System Access Points		N Profile	-		
WLANs WLAN Profile Network Settings	Profile Nar Profile Des				
Security	Number	S SID	Vap Description	Enable	Action
AAA	1	JetWave_2		Always Enabled	Edit
Management	2	JetWave_2			Edit
Tools	3	JetWave_2			Edit
Save Logout	4	JetWave_2			Edit
Reboot	5	JetWave_2			Edit
	6	JetWave_2			Edit
	7	JetWave_2			Edit
	8	JetWave_2			Edit

VAP configuration page

Click **Edit** in WLAN profile settings page to enter VAP configuration page. There will be 2 categories: basic settings and security settings.



Basic Settings

Vap Description:	
Wireless Network Name (SSID):	JetWave_2
Broadcast SSID:	Enabled Disabled
Wireless Separation:	Enabled
WMM Support:	Enabled Disabled
Max. Station Num:	64 (0-64)

Security Settings

Network Authentication:	Open System 🔻
Data Encryption:	None
Кеу Туре:	Hex 🔻
Default Tx Key:	Key 1 🔻
WEP Passphrase:	Generate Keys
Encryption Key 1:	
Encryption Key 2:	
Encryption Key 3:	
Encryption Key 4:	

Back OK Cancel

In basic settings:

VAP description: Enter the description of the VAP.

<u>Wireless Network Name (SSID)</u>: This wireless network name is shared among all associated devices in your wireless network. Keep it identical on all those devices. Note that the SSID is case-sensitive and cannot exceed 32 characters.

Broadcast SSID: Under AP mode, hiding network name is necessary when you are in a wireless environment that may have potential risk. By disabling broadcast SSID, the clients cannot scan and find the AP/Gateway, so that malicious attack by some illegal clients could be avoided.

<u>Wireless Separation</u>: Wireless separation is an ideal way to enhance the security of network transmission. Under the AP mode, enable "Wireless Separation" can prevent the communication among associated wireless clients.

WMM Support: WMM (Wi-Fi Multimedia) is a subset of 802.11e. It allows wireless communication to define a priority limit on the basis of data type, thus those time-sensitive data, like video/audio data, may own a higher priority than common one.

Beijer korenix Abeljer Electronics Group Company

JetWave IWC 5630 Series User Manual

<u>Max. Station Num:</u> In Wireless AP mode, you can define the maximum amount of wireless clients allowed to be connected. The maximum client of the system is 64. The most user access at the same time may cause system busy and the performance becomes lower. It is suggested to assign the value depends on how much bandwidth your client generally need, and totally bandwidth suggest is under 250Mbps for TCP based data transmission.

In security settings:

Network Authentication

Open System: It allows any device to join the network without performing any security check.

Shared Key: Data encryption and key are required for wireless authentication.

<u>WPA with RADIUS</u>: With warrant (username, password and etc.) offered by user, this kind of authentication can be realized with specific RADIUS server. This is the common way to be adopted in large enterprise network.

<u>WPA2 with RADIUS</u>: As a new version of WPA, only all the clients support WPA2, can it be available. If it is selected, AES encryption and RADIUS server is required.

WPA-PSK: It is a simplified WPA mode with no need for specific authentication server. In this so-called WPA Pre-Shared Key, all you have to do is just pre-enter a key in each WLAN node and this is the common way to be adopted in large and middle enterprise as well as residential network.

WPA2-PSK: As a new version of WPA, only all the clients support WPA2, can it be available. If it is selected, the data encryption can only be AES and the passphrase is required.

Data Encryption

If data encryption is enabled, the key is required and only sharing the same key with other wireless devices can the communication be established.

None: Available only when the authentication type is open system.

64 bits WEP: It is made up of 10 hexadecimal numbers.

128 bits WEP: It is made up of 26 hexadecimal numbers.

152 bits WEP: It is made up of 32 hexadecimal numbers.

TKIP: Temporal Key Integrity Protocol, which is a kind of dynamic encryption, is co-used with WPA-PSK.



<u>AES</u>: Advanced Encryption Standard, it is usually co-used with WPA2-PSK.

Eap Type: for WPA/WPA2 with Radius. The system supports **TTLS**, **LEAP**, **TLS**, **PEAP** and **MSCHAPv2**, **GTC** Eap types. Select the Eap type and type the <u>User Name</u>, <u>Password</u> for the WAP/WPA2 with Radius.

Press "Apply" to activate the setting.

Note:

- We strongly recommend you enable wireless security on your network!
- Only setting the same Authentication, Data Encryption and Key in the JetWave and other associated wireless devices, can the communication be established!

4.5 Network Settings


In **Network Settings** you can configure the network connectivity includes: IP settings, bridge table, ARP table, DHCP client list and NAT settings.

WLAN controller IWC 5630	IP Settings	
System Access Points WLANs	Use this page to configure the parameters for lo port of your Access Point. Here you may change etc	ocal area network which connects to the LAN the setting for IP address, subnet mask, DHCP,
Retwork Settings	WAN Settings :	
DIP Settings Bridge Table	WAN Access Type :	Static IP 🔻
ARP Table	IP Address :	192.168.1.1
DHCP Client List NAT Settings	Subnet Mask :	255.255.0
	Defente Ceterrary	

4.5.1 IP Settings

Use this page to configure WAN/LAN ports network settings.





IP Settings

Use this page to configure the parameters for local area network which connects to the LAN port of your Access Point. Here you may change the setting for IP address, subnet mask, DHCP, etc..

WAN Settings :	WAN	Settings	i
----------------	-----	----------	---

WAN Access Type :	Static IP 🔻
IP Address :	192.168.1.1
Subnet Mask :	255.255.255.0
Default Gateway :	192.168.1.254
DNS1:	0.0.0.0
DNS2:	0.0.0.0

LAN Settings :

IP Address :	192.168.10.1
Subnet Mask :	255.255.255.0
DHCP Server :	Disabled 🔻
DHCP IP Address Range Start :	192.168.10.100
DHCP IP Address Range End :	192.168.10.200
DHCP Subnet Mask :	255.255.255.0
DHCP Gateway :	192.168.10.1
WIN S1 :	0.0.00
WIN S2 :	0.0.0
Primary DNS Server :	8.8.8.8
Secondary DNS Server :	0.0.0
Lease Time(15-44640 Minutes) :	1440
Enable DHCP Relay	
DHCP Sever IP :	0.0.0

WAN Settings:

WAN Access Type: Static IP

IP Address: Once **Static IP** is selected, the IP Address field allows you to set the device's WAN IP address manually.

Subnet Mask: This is the subnet mask address for your WAN interface. Set the IP subnet mask manually.

Default Gateway: Set the default gateway IP address manually.

DNS 1 & 2: The Domain Name System (DNS) is how the Internet translates domain or website names into Internet addresses or URLs. Your ISP will provide you with at least one DNS Server IP Address. If you wish to use another, enter that IP Address in **DNS 2** field.

WAN Access Type: DHCP Client.



JetWave IWC 5630 Series User Manual

Once $\ensuremath{\text{DHCP}}$ Client is selected, the WAN interface acts as the DHCP Client and automatically

search the DHCP

WAN Set	tings :	
	WAN Access Type :	DHCP Client V

WAN ACCESS Type :	DHCP Client V
Host Name :	korenix9b7eab

LAN Settings:

IP Address: The IP Address field allows you to set the device's WAN IP address manually.

Subnet Mask: This is the subnet mask address for your WAN interface. Set the IP subnet mask

manually.

DHCP Server: Enabled / Disabled

LAN Settings :

IP Address :	192.168.10.2
Subnet Mask :	255.255.255.0
DHCP Server :	Enabled 🗸
DHCP IP Address Range Start :	192.168.10.100
DHCP IP Address Range End :	192.168.10.200
DHCP Subnet Mask :	255.255.255.0
DHCP Gateway :	192.168.10.1
WINS1 :	0.0.0.0
WINS2 :	0.0.0.0
Primary DNS Server :	8.8.8.8
Secondary DNS Server :	0.0.0.0
Lease Time(15-44640 Minutes) :	1440
Enable DHCP Relay	-
DHCP Sever IP :	0.0.0.0

Apply Cancel

4.5.2 Bridge Table

This table shows bridge table.



Bridge Table

This table shows bridge table.

MAC Address	\$ Interface 🗢	Ageing Timer(s) 🗢
00:23:7d:b6:36:17	Ethernet2	0.00
14:7d:c5:e8:9f:ac	Vvireless1	2.86
60:02:b4:78:66:ce	Wireless1	1.27

Refresh

MAC Address: The MAC address of the connected device.

Interface: This field shows the interface which learnt the MAC Address.

Aging Timer(s): The aging time of this entry. If the MAC didn't transmit any packet, the aging

time will start counting, and delete the entry after aging timeout.

Refresh: Refresh the table.

4.5.3 ARP Table

This table shows the ARP table.

ARP Table

This table shows ARP table.

IP Address: The IP Address leant from the interface.

MAC Address: The MAC Address leant from the interface.

Interface: The interface which learnt the ARP packet (IP and MAC Address).

Refresh: Refresh the table.

4.5.4 DHCP Client List

This table shows the assigned IP address, MAC address and expire timer of the connected DHCP client device.



DHCP Clients

This table shows the assigned IP address, MAC address and time expired for each DHCP leased client.

IP Address	MAC Address	Time Expired(s) ¢
192.168.10.100	68:76:4f:f3:86:78	86398

IP Address: The assigned IP address of the connected DHCP client device.

MAC Address: The MAC Address of the connected DHCP client device.

Time Expired(s): The DHCP expire timer connected DHCP client device. Time unit is second.

The number can be changed in DHCP Server Lease Time setting.

Refresh: Refresh the table.

4.5.5 NAT settings

NAT is the short of **Network Address Translation**, it is a methodology of modifying network address information in IP packet headers while they are in transit across a Gateway/Router for the purpose of remapping one IP address space into another. The simple type of NAT provides one to one translation of IP address. It can be used to interconnect two IP networks, normally one network is for Local Area Network and the other network is for Wide Area Network/Internet.

Use the "**NAT Settings**" pages to configure the NAT setting. There are two main configuration pages, "**Port Forwarding**" and "**DMZ**".

Port Forwarding

Entries in this table allow you to automatically redirect common network services to a specific machine behind the NAT firewall. These settings are only necessary if you wish to host some sort of server like a web server or mail server on the private local network behind your Gateway's NAT firewall.



Port Forwarding

Entries in this table allow you to automatically redirect common network services to a specific machine behind the NAT firewall. These settings are only necessary if you wish to host some sort of server like a web server or mail server on the private local network behind your Gateway's NAT firewall.

	Enable Port Public Port Range]-[]		
	IP Address:	· ·				
	Protocol:		Both	•		
	Port Range:			-		
	Comment:					
		Apply	Cancel			
	Local IP Address 🗘	Protoco	Port Range	Comment	Select	Edit ‡
Public Port Range						

Select "Enable Port Forwarding" and then type the parameters to create the port forwarding entries.

<u>Public Port Range</u>: Configure the port range which will be public to WAN/Internet. You can configure one or a range of TCP/UDP port number.

IP Address: Configure the IP Address of the LAN PC. The traffic from the public port range will be redirected to this IP address.

Protocol: Configure TCP, UDP or Both (TCP + UDP) protocol type.

Port Range: Configure the port range of the LAN, the traffic from the public port will be redirected to these port.

Comment: Add information of the entry.

Press "**Apply**" to activate the settings. After applied, there is one popup screen shows you already configured new entry. And then you can see the entries you configure in below.

• DMZ

A **Demilitarized Zone** is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains device accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.



DMZ

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers,SMTP (e-mail) servers and DNS servers.

Select "Enable DMZ" and assign the IP address of the "DMZ Host IP Address". This is the DMZ computer's IP address. If you configure the DMZ function for your office network, please make sure this is agreed by the IT administrator.

Press "Apply" to activate the settings.

4.6 Security

4.6.1 Firewall settings

The follow Firewall Settings pages to configure the Firewall setting. There are different types firewall settings, you can enable the setting, configure the rules, check the table you configured and Delete Select/All rules.

"Src IP Filtering": Source IP addresses Filtering from your LAN to Internet through the gateway.

"Dest IP Filtering": Destination IP addresses Filtering from the LAN to Internet through the gateway.

"Src Port Filtering": Source Ports Filtering from the LAN to Internet through the gateway.

"Dest Port Filtering": Destination Ports Filtering from the LAN to Internet through the gateway.

Source IP Filtering

Entries in this table are used to restrict certain types of data packets from your local network to internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.



JetWave IWC 5630 Series User Manual

Select "Enable Source IP Filtering", type the "Local IP Address" and "Comment" (note for

the entry) and then press "Apply" to activate the settings.

0							
Source IP	Filterir	ng					
Entries in this table a through the Gateway							rnet
through the Gateway	. Use of such flit	ers can be	neiprui in secur	ing o	restricting your in	ocal network.	
		Enabl	e Source IP Fi	Iterin	J		
	Loc	al IP Addre	ss:				
		Comment:		İ			
		Apply	Cancel				
Loca	I IP Address	\$	Comment	\$	Select	Edit	1
							1
				_			
	Delete S	Selected	Delete All	R	efresh		

After applied, the Web GUI will show "Change settings successfully". Click "OK" and then you can see the new entry shown in the below table.

Destination IP Filtering

Entries in this table are used to restrict the computers in LAN from accessing certain websites

in WAN according to IP address.

Select "Enable Destination IP Filtering", type the "Destination IP Address" and "Comment"

(note for the entry) and then press "Apply" to activate the settings.

Destinatio	on IP Filteri	na		
	re used to restrict the co	-	accessing certain we	bsites in WAN
	Enab	le Destination IP Filt	tering	
	Destination IP	Address:		
	Commer	nt:		
	Ар	ply Cancel		
Destinat	tion IP Address 🔶	Comment 🜩	Select	Edit
	I		n.	1
	Delete Selected	Delete All	Refresh	

After applied, the Web GUI will show "Change settings successfully". Click "OK" and then you can see the new entry shown in the below table.

Source Port Filtering

Entries in this table are used to restrict certain ports of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your Page 40



local network.

Select "<u>Enable Source Port Filtering</u>", type the "<u>Port Range</u>" of below "<u>Protocol</u>" type, the protocol type can be UDP, TCP or Both. Type the "<u>Comment</u>" (note for the entry) and then press "**Apply**" to activate the settings.

Source F Entries in this table through the Gatew	e are used to res	trict certain ports				
		Enable Sou	ırce Port Filtering	J		
		Port Range:		[
		Protocol: Comment:	Both	~		
		Apply	Cancel			
Source	e Port Range 🗢	Protocol 🗢	Comment	\$	Select	Edit
	80-88	TCP+UDP				Edit
	Delet	e Selected D	elete All Ref	fresh		

After applied, the Web GUI will show "Change settings successfully". Click "OK" and then you can see the new entry shown in the below table.

Destination Port Filtering

Entries in this table are used to restrict certain ports of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Entries in this table a	are used to res		of data packets from y ul in securing or restrict		
	5	Z Enable Destir	nation Port Filtering		
		Port Range:	-		
		Protocol:	Both 🗸		
		Comment:			
		Apply	Cancel		
Dest Po	ort Range 🗢	Protocol 🗢	Comment 🗢	Select	Edit
:	23	TCP	Telnet only		Edit

Select "Enable Destination Port Filtering", type the "Port Range" of below "Protocol" type,

the protocol type can be UDP, TCP or Both. Type the "Comment" (note for the entry) and



then press "**Apply**" to activate the settings.

After applied, the Web GUI will show "Change settings successfully". Click "OK" and then

you can see the new entry shown in the below table.

4.6.2 MAC ACL

This page allows you configure the Wireless Access Control list. You can configure Allow list or

Deny list for your wireless network on the AP/Gateway.

WLAN controller IWC 5630	
🕀 🧰 Monitor	Mac Access Control List
🖳 System	Entries in this table are used to restrict certain types of data packets from your local network to
Access Points	Internet through the Gateway. Use of such filters can be helpful in securing or restricting your
🕀 🧰 WLANs	local network.
🕮 🧰 Network Settings	
🖶 🛅 Security	Access Control Mode: Disable
	Mac Address:
MAC ACL	Comment:
AAA 💼	
🕀 🧰 Management	
Tools	Apply Cancel
- 🗋 Save	
Logout Reboot	Local Mac Address
	Delete Selected Delete All Refresh

Access Control Mode: Allow Listed or Deny Listed.

MAC Address: Type the MAC address of the client which you want to Allow or Deny.

<u>Comment:</u> fill in the comment of the rule.

Press "Apply" to activate the new settings.

The lower screen shows the Wireless Access Control list you configured. Press "Delete Selected"

or 'Delete All" to delete part of or all of the entries.

Press "Refresh" to refresh the table.

4.7 AAA

4.7.1 Radius settings

Use this page to configure the **RADIUS** Server Setting.

RADIUS (Remote Authentication Dial-In User Service) is a server for remote user authentication and accounting; it plays a central role in the network in providing the capabilities of authenticating, authorizing, accounting, alarming and etc. It allows an organization to maintain



user profiles in a central database that all remote servers can share.

Authentication RADIUS Server

R/	ADIUS Setti	ngs
Use	this page to set the radiu	is server settings.
Aut	hentication RADIUS	5 Server
	IP Address:	192.168.10.254
	Port:	1812
	Shared Secret:	1234
✓	Global-Key Update	
	Key renewal:	every 3600 Seconds
		Apply Cancel

IP Address: Enter the IP address of the Radius Server;

Port: Enter the TCP port number of the Radius Server; the default port number is 1812.

Shared Secret: This secret, which is composed of no more than 31 characters, is shared by the

device and RADIUS server during authentication.

Global-Key Update: Check this option and specify the time interval between two global-key

updates.

Key renewal: Set the time interval between two authentications.


4.7.2 Radius server

User database of built-in RADIUS can be managed in this configuration page.

🕆 🗋 WLAN controller IWC 5630				
🕀 🧰 Monitor	RADIUS Set	tings & Acco	ount	
System Access Points	Use this page to set the r	adius server settings.		
	Authentication RADIU	JS Server		
🕀 🧰 Network Settings	User ID:			
🖷 🧰 Security	User Name:			
RADIUS Settings	Password:			
Management	Repeat Password:			
■ Tools Save Logout		Apply	Cancel	
🗄 🗋 Reboot	SELECT	U SER ID	USER NAME	PASSWORD
		Chris	rd_dep2	*****
		Delete Delete	All Cancel	

User ID: The field is used to protect the mapping between an account and username. For

example, an account Chris uses username/password as rd_dep2/pwd_rd_dep2 to authenticate Page 43





with RADIUS server.

User name: The field will be used as username in RADIUS authentication.

Password: The field will be used as password in RADIUS authentication.

Repeat Password: The field is used to check whether the password matches.

4.8 Management

The "**Management**" feature set pages allow users to configure the remote settings, event warming type, SNMP, SMTP, password and firmware update, configuration file, certification file upload.

4.8.1 Remote Setting

Use this page to configure the remote management privacy, select the event warming type and SNMP settings.

en	note Management Pr	ivacy	
	✓ Telnet	SNMP	SNMP Trap
	SSH	Force HTTPS	Email Alert
ve	nt Warning Type		
	Wlan Association	Authentication Fail	Config Changed
N	AP Settings		
	Ū		
	Protocol Version:	V2 T	
	Protocol Version: Server Port:	V2	
	Server Port:	161	
	Server Port: Get Community:	161 public	

Remote Management Privacy: You can select which kinds of remote service should be opened

Beijer korenix ABujer Electronics Group Company

JetWave IWC 5630 Series User Manual

in your environment. The services include **Telnet**, **SNMP**, **SMP Trap**, **SSH**, **Force HTTPS** and **E-mail Alert.** Select the service and press "**Apply**" to activate the settings.

Event Warning Type: The event warming type selection.

Wian association: The client associated to the AP event.

Authentication Fail: The client failure of authentication event.

Config Changed: The configuration of the AP/Gateway is changed event.

SNMP Settings:

Protocol Version: Select the SNMP version, the product supports SNMP V1, V2c and V3. While selecting the SNMPv3, continue to configure the SNMPv3 User Name and Encryption in lower screen.

<u>Server Port:</u> Change the server port for a service if needed; however you have to use the same port to use that service for remote management.

<u>Get Community:</u> Specify the community name (password) for the incoming SNMP_Get and SNMP_GetNext requests from the management station. By default, it is set to public and allows all requests.

<u>Set Community:</u> Specify the community name (password) for the incoming SNMP_Set requests from the management station. By default, it is set to private.

Trap Destination: Specify the IP address of the station to send the SNMP traps to.

<u>Trap Community:</u> Specify the community name (password) sent with each trap to the manager. By default, it is set to public and allows all requests.

Note: For security concern, it is recommended change the Community Name before you connect the WLAN controller to the network. The experience engineer who familiar with SNMP protocol can easily discovery and change the configuration of the WLAN controller through SNMP once you use the default communication name.



4.8.2 SMTP Configuration

The AP/Gateway supports E-mail Warning feature. The AP/Gateway will send the occurred events to remote E-mail server. The receiver can then receive notification by E-mail. The E-mail warning is conformed to SMTP standard. This page allows you to enable E-mail Alert, assign the SMTP Server IP, Sender E-mail, and Receiver E-mail. If SMTP server requests you to authorize first, you can also set up the username and password in this page.

SMTP Settings

Use this page to setup Email Alert of remote console.

Configure SMTP Setting

SMTP Server IP:	
Email Account:	
Authentication Protocol:	None V
User Name:	
Password:	
Confirm Password:	
Rcpt Email Address 1:	
Rcpt Email Address 2:	

Apply Cancel

SMTP Server IP: The IP address of the SMTP Server.

Email Account: The sender's Email Account.

Authentication Protocol: If SMTP server requests you to authorize first, select the

Authentication Protocol and following User Name and Password.

User Name: The User Name of the Sender Email account.

Password: The Password of the Sender Email account.

Confirm Password: Confirm the Password of the Sender Email account.

Rcpt Email Address 1: The first Receiver's email address.

Rcpt Email Address 2: The second Receiver's email address.

Press "Apply" to activate the setting.



4.8.3 Password Settings

Use this page to set the password of the AP/Gateway.

Type the New Password and Confirm Password again. Press "Apply" to activate the new

password.

Password Settings

Use this page to set the password of this Access Point.

New Password:	
Confirm Password:	
Apply Cano	cal

4.8.4 Firmware Upgrade

In this section, you can update the latest firmware for your AP/Gateway. Korenix provides the latest firmware in Korenix Web site. The new firmware may include new features, bug fixes or other software changes. We'll also provide the release notes for the update as well.

From technical viewpoint, we suggest you use the latest firmware before installing the AP/Gateway to the customer site.

Note that the system will be automatically rebooted after you finished upgrading new firmware.

Please remind the attached users before you do this.

Firmware Upgrade

is page allows you upgrade the device firmware to a new version. Please do not power off the device ring the upload because it may crash the system.			
Select File:		Browse	
	Upgrade Cancel		

Type the path of the firmware in <u>Select File:</u> field. Or click "<u>Browse...</u>" to browse the firmware file. Press "**Upgrade**" to upload the firmware file to the WLAN controller. After finishing transmitting the firmware, the system will copy the firmware file and replace the firmware in the flash. During the progress, please **DO NOT** power off your system.



4.8.5 Configuration File

The AP/Gateway provides Configuration File Backup (Save Setting to File), Restore (Load

Setting from File) and Reset Setting to Default features.

With Backup command, you can save current configuration file saved in the WLAN controller's flash to admin PC. This will allow you to go to Restore command later to restore the configuration file back to the WLAN controller. Before you restore the configuration file, you must place the backup configuration file to specific folder in the PC. Users can also browse the target folder and select existed configuration file. The WLAN controller can then download this file back to the flash. This **Browse...** mode is only provided by Web UI. For CLI, please type specific path of the configuration file.

Configuration File

This page allows you to save current settings to a file or load the settings from the file which was saved previously. Besides, you could reset the current configuration to factory default or reboot the device.

Load Settings from File:	Browse Upload		
Save Settings to File:	Save		
Reset Settings to Default:	Reset Include IP Settings		

Backup (Save Setting to File): Press "Save..." to backup the configuration file to specific path/folder in your computer.

Restore (Load Setting from File): Type the path of the configuration file or click "<u>Browse...</u>" to browse the firmware file. The Browse feature is only supported in Web GUI. Press "**Upload**" after the file is selected.

Reset Settings to Default: Press "**Reset**" can reset all the configurations, but not included default IP address to default settings. If you want to reset the IP address to default value, select "Include IP Settings".



4.8.6 Certificate File

Use this page to import/delete user certificate file.

Certificate Settings

Use this page to upload/delete user certificate.

Delete User Certificate:	client.pfx	•	Delete
Import User Certificates:	Browse		Import

You can import user certificate file, select "**Browse**..." to select the certificate file and press "**Import**". You can generate the file by 3rd tool, web site or get from the IT administrator.

Following is the security setting under "WPA with Radius" Authentication mode, the EAP type is TLS. You can see the "User Certificate file" is assigned. The AP must use the same certificate file as your Radius Server under this setting.

Security Settings	
Network Authentication:	WPA with Radius
Eap Type:	TLS V
Loginname:	wifi-user
User Certificate:	client.pfx •
Password:	· · · · · · · · · · · · · · · · · · ·
	Network Authentication: Eap Type: Loginname: User Certificate:



4.9 Tools

The "**Tools**" feature set pages provides some additional useful tools. The System Log help you see the occurred event logs, wireless AP site survey, Ping Watchdog, Data Rate Test, Antenna Alignment and Ping tool.

4.9.1 System Log

Use this page to set remote log server and show the system log.

System Log

	Enable	Remote Syslog Serve	er		
	IP Address:	IP Address: 0.0.0.0			
	Port:		514		
Apply Cancel					
		Source	+	Message	+
# \$	Time 🗧	Source		-	

Select "Enable Remote Syslog Server", type the IP Address and Port number of your syslog

server. The default port number is 514.

Press "Apply" to activate the setting.

In the lower screen, it displays the occurred system logs. Each entry has the index, occurred time, source MAC address and the message. You can monitor the system by this screen, however, the logs will be removed after system reboot.

Press "Clear" allows you to remove all of entries.

Press "**Refresh**" allows you to refresh the table.



4.9.2 Ping

This is a simple Ping tool for you to check the status of remote station.

Type the target IP address in the "**Destination:_____**" field then press "**Ping**".

The system will ping the remote station 4 times and list the ping result in the web GUI.

Ping

This page provides a tool to Ping IP address.

Destination:
Ping
PING 192.168.10.95 (192.168.10.95): 56 data bytes 64 bytes from 192.168.10.95: icmp_seq=0 ttl=128 time=0.5 ms 64 bytes from 192.168.10.95: icmp_seq=1 ttl=128 time=0.6 ms 64 bytes from 192.168.10.95: icmp_seq=2 ttl=128 time=0.7 ms 64 bytes from 192.168.10.95: icmp_seq=3 ttl=128 time=0.5 ms
192.168.10.95 ping statistics 4 packets transmitted, 4 packets received, 0% packet loss round-trip min/avg/max = 0.5/0.5/0.7 ms



4.10 Main Entry

The main entry provides the system tools, for example Save the configuration, Logout and Reboot the system.

4.10.1 Save

Use this page to save configuration to flash. Every time while you finished the configuring the device, please remember to save the configuration to flash. Otherwise, the configuration will be lost after reboot the system.

Save

Use this page to save configuration to flash.

Do you want to save configuration to flash?

Press "Save to Flash" to save the configuration to flash.

4.10.2 Logout

After finished configuring and leave, please remember to Logout the system. Without Logout the system, the login session will not timeout for couple minutes, it is a risk that other user may login your system without password checking before timeout. Another affect is that the user can NOT access at the same time if someone already login the system.

Use this page to logout. Press "Yes" to logout.

Logout

Use this page to logout.
Do you want to logout?
Yes

4.10.3 Reboot

Use this page to reboot the system. Press "Yes" to reboot system.

Reboot

Use this page to Reboot.

Do you want to reboot?

Yes



The below warming message will appear after you reboot the system.

This device has been reboot, you have to login again. Please wait for **72** seconds before attempting to access the device again...



JetWave IWC 5630 Series User Manual





Chapter 6 Troubleshooting



Chapter 6 Troubleshooting

This chapter provides troubleshooting procedures for basic problems with the JetWave IWC 5630. For warranty assistance, contact your service provider or distributor for the process.

5.1 General Question

5.1.1 How to know the MAC address of the WLAN controller?

MAC Address distinguishes itself by the unique identity among network devices. There are two ways available to know it.

Each device has a label posted on the side of the controller. There are MAC addresses for Ethernet. On the Web-based management interface, you can view the MAC Address from "Monitor" -> "Information".

5.1.2 What if I would like to reset the unit to default settings?

You may restore factory default settings by click the "**Reset**" button above 7 seconds. By press Reset button, you will reset the IP address to default IP 192.168.10.1.

Or you can reset the unit to default setting in Web GUI. You can reserve the IP address setting.

5.1.3 What if I cannot access the Web-based management interface?

Please check the followings:

- Check whether the IP address of PC is correct (in the same network segment as the unit)
- Login the unit via other browsers such as Firefox, Google Chrome.
- If everything is correct, but, you still can't access the web GUI, we suggest you connect the console cable to do further checking. Please refer to the pin assignment in hardware installation chapter.
- Check whether the power supply is OK; Try to power on the unit again. If the web GUI can't be accessed issue occurred again, please contact our technical service engineer. We may ask you connect console cable and provide us more information.



Revision History

Version	Description	Date	Editor
V1.0	1 st release for JetWave IWC 5630	Sep, 2015	Latrell Wang